

IAG Bronco Front Mud Flaps

For 2021+ Bronco





IAG-BDY-F1302 IAG Bronco Front Mud Flaps For 2021+ Bronco

Congratulations on the purchase of your IAG Bronco Front Mud Flaps, and thank you for choosing IAG Off Road! These instructions are intended for users with basic mechanical skills. Professional installation is not required.

Installation video can be found on our website, or by using the the following QR code.

Scan QR code for instruction video.





- 1** Left Front Mud Flap
- 2** Right Front Mud Flap
- 3** (X2) Front Inner Bracket
- 4** (X2) Front Outer Bracket
- 5** (X4) 5mm Allen bolts
(X4) 10mm nuts
(X8) Washers
- 6** (X2) Push Clips

Tools needed:

10mm socket, 5mm Allen wrench, Pocket screwdriver and trim pry tool.



Step 1

Remove the front fender flare from the drivers side.

Rotate the locking tabs on the inside of the fender flare 90° to disengage the tabs.



Step 1 pt. 2

Pull the fender flare away from the vehicle using even force, and set fender flare aside.



Step 2

Using a pry tool, remove the four lower push clips of the front fender liner.

Fold the fender liner aside.



Step 3

Prepare the Front Inner Bracket.

Install the bracket behind the fender with the studs facing out.

3



Step 4

Reinstall the fender liner, reuse one of the factory push clips as shown.



Step 5

Prepare the Front Outer Bracket and two 10mm nuts.

Install the bracket onto the studs. Use 10mm nuts and washers, then tighten.

4





Step 6

Prepare LF Mud Flap and two 5mm Allen Bolts.

Install Mud Flap onto the outer bracket, use Allen bolts and washers. Do not tighten.



Step 7

Prepare one of the provided push clips.

Install push clip into mudflap.



Step 8

Reinstall the fender flare.

Rotate the locking tabs 90° to secure the flare.



Step 9

Adjust Mud Flap to align with fender flare, then tighten the mudflap hardware.



Step 10

Repeat for other side.



If you have any questions about the product or install please reach out to support@iagoffroad.com or call 410-840-3555