



# U.S. BASED SUPPORT

**HOURS: MONDAY - FRIDAY | 8AM - 5PM EST**



[1.410.840.3555](tel:14108403555)



[support@iagoffroad.com](mailto:support@iagoffroad.com)



**VIDEO INSTRUCTIONS**

<https://www.youtube.com/watch?v=W6w95XiciqA>





## **IAG V3 Drop Step For 2021+ Bronco**

### **IAG V3 Drop Step for 2021+ Bronco**

**Part Number: IAG-BDY-F2227**

Congratulations on the purchase of your Drop Step, and thank you for choosing IAG Offroad! These instructions are intended for users with basic mechanical skills. Professional installation is not required.

#### **Product includes:**

<b>1</b>	(X2) IAG Drop Step	<b>3</b>	(X8) 2.5mm Allen Bolt
<b>2</b>	(X2) Logo Plate	<b>4</b>	(X8) 7mm Nut



#### **Tools Needed:**

- 3mm Allen Wrench
- 10mm Wrench
- 2.5mm Allen Wrench
- 7mm Wrench



Scan Me



**Step 1:** Prepare the IAG Drop Step. Back out the mounting studs by hand until the end is flush with the bracket.

**Step 2:** Install the IAG Drop Step onto the front of the factory Rock Rail. Adjust step to desired position.



**Step 3:** Using a 3mm Allen Wrench, tighten the Mounting Studs until snug against the Rock Rail.

**Step 4:** Using a 10mm Wrench, tighten the Jam Nuts until snug.



**Step 5:** Prepare the IAG Logo Plate and four provided 2.5mm Allen Bolts. Align the Logo Plate and install Bolts.

**Step 6:** Install provided 7mm nuts onto the Allen Bolts and tighten.  
**Repeat for other side.**



If you have any questions about the product or install  
please reach out to [support@iagoffroad.com](mailto:support@iagoffroad.com) or call  
**410-840-3555**