



U.S. BASED SUPPORT

HOURS: MONDAY - FRIDAY | 8AM - 5PM EST



[1.410.840.3555](tel:14108403555)



support@iagoffroad.com



VIDEO INSTRUCTIONS

<https://www.youtube.com/watch?v=DHTVrMxqu34&t=1s>





***IAG I-Line Recovery Shackles
For 2021+ Bronco Modular Bumper
and IAG Capable Recovery Points***

I-Line Recovery Shackles for 2021+ Bronco

Part Number: IAG-BDY-F3198

Congratulations on the purchase of your Shackles, and thank you for choosing IAG Offroad! These instructions are intended for users with basic mechanical skills. Professional installation is not required.

Product includes:

- 1 (X2) Shackles**
- 2 Provided Torx 20 Wrench**



Tools Needed:

Provided Torx 20 Wrench





Step 1:
Remove the Torx 20 Retaining Bolt from the Shackle using the provided wrench.



Step 2:
Remove the Shackle Nut from the Bolt.



Step 3:
Remove the Shackle Bolt and Rubber Washers from the shackle.



Step 4:
Install the Shackle onto the vehicle. Install the Shackle Bolt with Rubber Washers.

Use appropriate thickness of washers for gap.



Step 5:
Install the Shackle Nut onto the Bolt hand tight. Do not tighten with wrench.

Reinstall the Torx20 Retaining Bolt with provided wrench and tighten.



If you have any questions about the product or install please reach out to support@iagoffroad.com or call 410-840-3555